



SYSTEMS

PARTS CATALOGUE

PARTS FOR AIR ASSIST

Edition 1.0

AIR BELLOW / AIR SPRINGS

Air Spring AL-KO 07 (HD + B + C)	OP.LB02716AAA01	4
Air Spring AL-KO 07 HD incl. Nylon Disc	SA.LB.ALKOH	4
Air Spring AL-KO 07 B and C incl. Nylon Disc	SA.LB.ALKOB	4
Air Spring Dunlop SZ5520	OP.LB.DU.SZ5520	5
Air Spring Dunlop SZ5520 fitting left	OP.LB.DU.SZ5520.L	5
Air Spring Dunlop SZ5520 fitting outside	OP.LB.DU.SZ5520.O	5
Air Spring Dunlop SZ5520 fitting right	OP.LB.DU.SZ5520.R	5
Air bellow 130-3	OP.LB.130-3.CPL	6
Air bellow 130-3 Iveco Daily S (2014 →)	OP.LB.130-3.CPL.S14	6
Air bellow 170-2	OP.LB.170-2.CPL	6
Air bellow 170-3	OP.LB.170-3.CPL	6

SPACER / BRIDGES

Set spacers 30 mm L+R L.AL.02	SB.L.AL.02.30	7
Set spacers 50 mm L+R L.AL.02	SB.L.AL.02.50	7
Set spacers 80 mm L+R L.AL.02	SB.L.AL.02.80	7
Set spacer bridge L+R L.AL.07 (HD)	SB.L.AL.07(HD)	8
Set spacer bridge L+R L.AL.07 (B1) 80-100	SB.L.AL.07(B1)	8
Set spacer bridge L+R L.AL.07 (B2) 40-60	SB.L.AL.07(B2)	9
Set spacer bridge L+R L.AL.07 (C)	SB.L.AL.07(C)	9

PLANE PANELS

Panel plane Option 1 and 2	PAN.OPTION1&2	10
Panel plane Option 1 and 2 X244 (LHD)	PAN.X244	10
Panel plane Option 1 and 2 X244 (RHD)	PAN.X244R	10
Panel plane Option 1 and 2 X250 (LHD)	PAN.X250	11
Panel plane Option 1 and 2 X250 (RHD)	PAN.X250R	11
Panel plane Option 1 and 2 Transit '06 → '14	PAN.FORD06	11
Panel plane Option 1 and 2 Transit '14 →	PAN.FORD14	11
Panel plane Option 1 and 2 Iveco '14 → (LHD)	PAN.IVE.14	12
Panel plane Option 1 and 2 Iveco '14 → (RHD)	PAN.IVE.14R	12
Panel plane Option 1 and 2 Master X62	PAN.X62	12
Panel plane Option 1 and 2 Crafter / MAN TGE (LHD)	PAN.CRA17	12
Panel plane Option 1 and 2 Crafter / MAN TGE (RHD)	PAN.CRA17R	13
Panel plane Option 1 and 2 DIN1	PAN.DIN1	13
Panel plane Option 3	PAN.OPTION3	14
Panel plane Option 3 X250 (LHD)	PAN.OPITON3.X250	14
Panel plane Option 3 X250 (RHD)	PAN.OPTION3.X250R	15
Panel plane Option 3 DIN1	PAN.OPTION3.DIN1	15

OPERATING PANELS OPTION 1

Operating panel Option 1 Standard	LC.P.OP1.STA	18
Operating panel Option 1 X244 (LHD)	LC.P.OP1.X244	18
Operating panel Option 1 X244 (RHD)	LC.P.OP1.X244R	18
Operating panel Option 1 X250 (LHD)	LC.P.OP1.X250	19
Operating panel Option 1 X250 (RHD)	LC.P.OP1.X250R	19
Operating panel Option 1 Transit '06 → '14	LC.P.OP1.FORD06	19
Operating panel Option 1 Transit '14 →	LC.P.OP1.FORD14	19
Operating panel Option 1 Master X62	LC.P.OP1.X62	20
Operating panel Option 1 DIN1	LC.P.OP1.DIN1	20
Operating panel Option 1 Iveco '14 → (LHD)	LC.P.OP1.IVE.14	21
Operating panel Option 1 Iveco '14 → (RHD)	LC.P.OP1.IVE.14R	21
Operating panel Option 1 Crafter / MAN TGE (LHD)	LC.P.OP1.CRA17	21
Operating panel Option 1 Crafter / MAN TGE (RHD)	LC.P.OP1.CRA17R	21

OPERATING PANELS OPTION 2

Operating panel Option 2 Standard	LC.P.OP2.STA	22
Operating panel Option 2 X244 (LHD)	LC.P.OP2.X244	22
Operating panel Option 2 X244 (RHD)	LC.P.OP2.X244R	22
Operating panel Option 2 X250 (LHD)	LC.P.OP2.X250	23
Operating panel Option 2 X250 (RHD)	LC.P.OP2.X250R	23
Operating panel Option 2 Transit '06 → '14	LC.P.OP2.FORD06	23
Operating panel Option 2 Transit '14 →	LC.P.OP2.FORD14	23

24	Operating panel Option 2 Iveco '14 → (LHD)	LC.P.OP2.IVE.14
24	Operating panel Option 2 Iveco '14 → (RHD)	LC.P.OP2.IVE.14R
24	Operating panel Option 2 Crafter / MAN TGE (LHD)	LC.P.OP2.CRA17
24	Operating panel Option 2 Crafter / MAN TGE (RHD)	LC.P.OP2.CRA17R
25	Operating panel Option 2 Master X62	LC.P.OP2.X62
25	Operating panel Option 2 DIN1	LC.P.OP2.DIN1

OPERATING PANELS OPTION 3

26	Operating panel Option 3	LC.P.OP3
26	Operating panel Option 3 X250 (LHD)	LC.P.OP3.X250
27	Operating panel Option 3 X250 (RHD)	LC.P.OP3.X250R
27	Operating panel Option 3 DIN 1	LC.P.OP3.DIN1

COMPRESSOR PARTS

28	Option 2 Compressor with pneumatic parts	OPTION2.C5PE
28	Option 2 Compressor Complete	OPTION2.C5PEC
28	Assembly Pneumatic part Option 2 Comp	OP.TRK.SA.OPT.2
29	Option 3 Compressor with pneumatic parts	OPTION3.C5PE
29	Option 3 Compressor Complete	OPTION3.C5PEC
29	Assembly Pneumatic part Option 3 Comp	OP.TRK.SA.OPT.3

OPTION PANEL PARTS

30	Bracket for inflate valves	1.21.01
30	Inflate valve	SA.VENT.5MM
30	Cap for inflate valve	OP.VENT.DOP
30	Inner valve for inflate / deflate valve(s)	OP.VENT.BW
30	Blind cap	OP.DIV.BLINDST
30	Pressure Gauge Dunlop Manometer 0-10 bar	OP.MANO.DSC.10
30	Deflate valve	SA.VENT.OPTION2
30	Deflate button	L.ONT.VENT.KNOP
31	Operating switch	OE.SCHAK.WIP.ZW
31	Push button inflate / deflate	OP.VT.CP.BLM
31	Push button inflate valve used for up	OP.VT.CP.UP
31	Push button deflate valve used for down	OP.VT.CP.DOWN

OTHER OPTION PARTS

33	One way valve (check valve) 1/8" BSP mail: 1/8" BSP Female	OPN.TRK.MF.1/8W
33	Fuse	OE.ZE.VZ.25A
33	Fuse holder	OE.ZE.FHA.14L
33	Pressure switch	OE.DS.OP3.7.5-10
33	Relays	OE.RL.20200100M
33	Air tank	OP.DT.YE.0.5G

CONNECTION PARTS 5 MM

34	Air hose 5 mm, 5 meter Black and 5 meter Blue	OPS.5X3.BLZW5
34	Air hose 5 mm 10 meter Blue	OPS.5X3.BL10
34	Air hose 5 mm 10 meter Black	OPS.5X3.ZW10
34	Air hose 5 mm 10 meter green	OPS.5X3.GR10
35	Fitting 1/8" BSP x 5mm air hose	OPN.OR.5*1/8
35	Elbow fitting 1/8" BSP x 5mm air hose	OPN.OK.5*1/8
35	Connector 5 mm air hose x 5 mm air hose	OPN.OV.5*5
35	Fitting 5 mm air hose x M5	OPN.OR.5*M5
35	T-connector. 5 mm air hose at all sides	OPN.OT.5
35	Connector 5 mm air hose x 6 mm air hose	OPN.OV.5*6

CONNECTION PARTS 4 MM

36	Fitting 1/8" BSP x 4mm air hose	OPN.OR.4*1/8
36	Elbow fitting 1/8" BSP x 4mm air hose	OPN.OK.4*1/8
36	Connector 4 mm air hose x 4 mm air hose	OPN.OV.4*4
36	Connector 4 mm air hose x M5	OPN.OR.4*M5
36	T-connector. 4 mm air hose x 4 mm at all sides	OPN.OT.4

FOR OTHER DIAMETERS

37	Connector 4 mm air hose x 5 mm air hose	OPN.OV.4*5
37	Connector 4 mm air hose x 6 mm air hose	OPN.OV.4*6





Air Spring AL-KO 07 (HD+B+C)


OP.LB02716AAA01

**Description**
6"Air Spring.

Design height	19 cm
Load Force (max.) at 7 bar	8.2 kN
Load Force (min.) at 3 bar	3.4 kN
Diameter at 5 bar	15.7 cm
Incl. 5 mm air hose connector	

Air Spring AL-KO 07 HD incl. Nylon Disc

SA.LB.ALKOH

**Description**
6"Air Spring.

Design height	19 cm
Load Force (max.) at 7 bar	8.2 kN
Load Force (min.) at 3 bar	3.4 kN
Diameter at 5 bar	15.7 cm
Incl. 5 mm air hose connector	

Air Spring AL-KO 07 B and C incl. Nylon disc


SA.LB.ALKOB

**Description**
6"Air Spring.

Design height	19 cm
Load Force (max.) at 7 bar	8.2 kN
Load Force (min.) at 3 bar	3.4 kN
Diameter at 5 bar	15.7 cm
Incl. 5 mm air hose connector	

Air Spring Dunlop SZ5520


OP.LB.DU.SZ5520

**Description**
4"Air Spring.

Design height	19 cm
Load Force (max.) at 7 bar	5.3 kN
Load Force (min.) at 3 bar	2.1 kN
Diameter at 5 bar	11.5 cm
5 mm air hose connector pointing: straight	

Air Spring Dunlop SZ5520 fitting left


OP.LB.DU.SZ5520.L

**Description**
4"Air Spring.

Design height	19 cm
Load Force (max.) at 7 bar	5.3 kN
Load Force (min.) at 3 bar	2.1 kN
Diameter at 5 bar	11.5 cm
5 mm air hose connector pointing: left	

Air Spring Dunlop SZ5520 fitting outside


OP.LB.DU.SZ5520.O

**Description**
4"Air Spring.

Design height	19 cm
Load Force (max.) at 7 bar	5.3 kN
Load Force (min.) at 3 bar	2.1 kN
Diameter at 5 bar	11.5 cm
5 mm air hose connector pointing: outside	

Air Spring Dunlop SZ5520 fitting right


OP.LB.DU.SZ5520.R

**Description**
4"Air Spring.

Design height	19 cm
Load Force (max.) at 7 bar	5.3 kN
Load Force (min.) at 3 bar	2.1 kN
Diameter at 5 bar	11.5 cm
5 mm air hose connector pointing: right	

Air bellow 130-3

OP.LB.130-3.CPL

**Description**


Air bellow 130-3.

Design height	17 cm
Load Force (max.) at 7 bar	3.9 kN
Load Force (min.) at 3 bar	1.6 kN
Diameter at 5 bar	14 cm

Incl. 5 mm air hose connector

Air bellow 130-3 Iveco Daily S (2014 →)

OP.LB.130-3.CPL

**Description**

Air bellow 130-3.

Design height	17 cm
Load Force (max.) at 7 bar	3.9 kN
Load Force (min.) at 3 bar	1.6 kN
Diameter at 5 bar	14 cm

Incl. 5 mm air hose connector for Iveco Daily S (2014 →)

Air bellow 170-2

OP.LB.170-2.CPL

**Description**

Air bellow 170-2.

Design height	13.5 cm
Load Force (max.) at 7 bar	9.2 kN
Load Force (min.) at 3 bar	3.9 kN
Diameter at 5 bar	18 cm

Incl. 5 mm air hose connector

Air bellow 170-3

OP.LB.170-3.CPL

**Description**

Air bellow 170-3.

Design height	19 cm
Load Force (max.) at 7 bar	10.5 kN
Load Force (min.) at 3 bar	4.5 kN
Diameter at 5 bar	18 cm

Incl. 5 mm air hose connector



Set spacers 30 mm L+R L.AL.02

SB.L.AL.02.30

**Description**

3cm piston extension for air spring OP.LB.DU.S25520.

Outside diameter (D)	80 mm
Inside diameter (d)	10 mm
Height (h)	30 mm
Including	Allen screws M12 x 70 + matching rings

Set spacers 50 mm L+R L.AL.02

SB.L.AL.02.50

**Description**

5cm piston extension for air spring OP.LB.DU.S25520.

Outside diameter (D)	80 mm
Inside diameter (d)	10 mm
Height (h)	50 mm
Including	Allen screws M12 x 90 + matching rings

Set spacers 80 mm L+R L.AL.02

SB.L.AL.02.80

**Description**

8cm piston extension for air spring OP.LB.DU.S25520.

Outside diameter (D)	80 mm
Inside diameter (d)	10 mm
Height (h)	80 mm (50+30)
Including	Allen screws M12 x 120 + matching rings

Set spacer bridges L+R L.AL.07 (HD)

SB.L.AL.07(HD)

**Description**

6cm - 8cm drive height extension for L.AL.07(HD).

Fits for AL-KO

Fiat Ducato
Citroën Jumper / Relay
Peugeot Boxer

Year

2006 - onwards

Including

Screws for installation

Chassis height

29 cm - 31 cm

* For more information see our Air Assist Kits Catalogue

Set spacer bridges L+R L.AL.07 (B2) 40-60

SB.L.AL.07(B2)

**Description**

3cm - 6cm drive height extension for L.AL.07(B2).

Fits for

Fiat Ducato
Citroën Jumper / Relay
Peugeot Boxer

Year

2006 - onwards

Including

Screws for installation

Chassis height

26 cm - 29 cm

* For more information see our Air Assist Kits Catalogue

Set spacer bridges L+R L.AL.07 (B1) 80-100

SB.L.AL.07(B1)

**Description**

6cm - 8cm drive height extension for L.AL.07(B1).

Fits for

Fiat Ducato
Citroën Jumper / Relay
Peugeot Boxer

Year

2006 - onwards

Including

Screws for installation

Chassis height

29 cm - 31 cm

* For more information see our Air Assist Kits Catalogue

Set spacer bridges L+R L.AL.07 (C)

SB.L.AL.07(C)

**Description**

6cm - 8cm drive height extension for L.AL.07(C).

Fits for

Fiat Ducato
Citroën Jumper / Relay
Peugeot Boxer

Year

2006 - onwards

Including

Screws for installation

Chassis height

51 cm - 53 cm

* For more information see our Air Assist Kits Catalogue





Panel plane Option 1 and 2

PAN.OPTION1&2

**Description**

Standard rectangle panel.

Width	160 mm
Height	65 mm
Including	Blind stop for Option 1 Screws for installation

Panel plane Option 1 and 2 X244 (LHD)

PAN.X244

**Description**

Special dashboard panel.

Fits for	Fiat Ducato X244 Citroën Jumper / Relay Peugeot Boxer
Year	2002 - 2006
Suitable for	Left Hand Drive
Including	Blind stop for Option 1 Screws for installation

Panel plane Option 1 and 2 X244 (RHD)

PAN.X244R

**Description**

Special dashboard panel.

Fits for	Fiat Ducato X244 Citroën Jumper / Relay Peugeot Boxer
Year	2002 - 2006
Suitable for	Right Hand Drive
Including	Blind stop for Option 1 Screws for installation

Panel plane Option 1 and 2 X250 (LHD)

PAN.X250

**Description**

Special dashboard panel.

Fits for	Fiat Ducato X250 Citroën Jumper / Relay Peugeot Boxer
Year	2006 - onwards
Suitable for	Left Hand Drive
Including	Blind stop for Option 1 Screws for installation

Panel plane Option 1 and 2 X250 (RHD)

PAN.X250R

**Description**

Special dashboard panel.

Fits for	Fiat Ducato X250 Citroën Jumper / Relay Peugeot Boxer
Year	2006 - onwards
Suitable for	Right Hand Drive
Including	Blind stop for Option 1 Screws for installation

Panel plane Option 1 and 2 Transit '06 - '14

PAN.FORD06

**Description**

Special dashboard panel for Ford Transit.

Fits for	Ford Transit
Year	2006 - 2014
Suitable for	Left and Right Hand Drive
Including	Blind stop for Option 1 Screws for installation

Panel plane Option 1 and 2 Transit '14 -

PAN.FORD14

**Description**

Special dashboard panel for Ford Transit.

Fits for	Ford Transit
Year	2014 - onwards
Suitable for	Left and Right Hand Drive
Including	Blind stop for Option 1 Screws for installation

Panel plane Option 1 and 2 Iveco '14 - (LHD)

PAN.IVE.14

**Description**

Special dashboard panel for Iveco Daily.

Fits for	Iveco Daily
Year	2014 - onwards
Suitable for	Left Hand Drive
Including	Blind stop for Option 1 Screws for installation

Panel plane Option 1 and 2 Iveco '14 - (RHD)

PAN.IVE.14R

**Description**

Special dashboard panel for Iveco Daily.

Fits for	Iveco Daily
Year	2014 - onwards
Suitable for	Right Hand Drive
Including	Blind stop for Option 1 Screws for installation

Panel plane Option 1 and 2 Master X62 (2010 - 2019)

PAN.X62

**Description**

Special dashboard panel.

Fits for	Renault Master X62 Nissan Interstar X62 Opel Movano X62
Year	2010 - 2019
Suitable for	Left and Right Hand Drive
Including	Blind stop for Option 1 Screws for installation

Panel plane Option 1 and 2 Crafter / MAN TGE (LHD)

PAN.CRA17

**Description**

Special dashboard panel for MAN TGE and Crafter.

Fits for	MAN TGE Volkswagen Crafter
Year	2017 - onwards
Suitable for	Left Hand Drive
Including	Blind stop for Option 1 Screws for installation

Panel plane Option 1 and 2 Crafter / MAN TGE (RHD)

PAN.CRA17R

**Description**

Special dashboard panel for MAN TGE and Crafter.

Fits for	MAN TGE Volkswagen Crafter
Year	2017 - onwards
Suitable for	Right Hand Drive
Including	Blind stop for Option 1 Screws for installation

Panel plane Option 1 and 2 DIN1

PAN.DIN1

**Description**

Special dashboard panel DIN1. Fits in most radio positions.

Fits for	Mercedes Sprinter WDB 906 (2006 - 2018) Renault Master ('98 - '10), ('19 - onwards) Opel/Vauxhall Movano ('98 - '10), ('19 - onwards) Nissan Interstar ('98 - '10), ('19 - onwards) Iveco (2006 - onwards)
Width	188 mm
Height	60.5 mm
Suitable for	Left and Right Hand Drive
Including	Blind stop for Option 1 Screws for installation



Panel plane Option 3

PAN.OPTION3

**Description**

Standard rectangle panel.

Width	185 mm
Height	65 mm
Suitable for	Left and Right Hand Drive
Including	Screws for installation

Panel plane Option 3 X250 (RHD)

PAN.OPTION3.X250R

**Description**

Special dashboard panel.

Fits for	Fiat Ducato X250 Jumper / Relay	Citroën Peugeot Boxer
Year	2006 - onwards	
Suitable for	Right Hand Drive	
Including	Screws for installation	

Panel plane Option 3 X250 (LHD)

PAN.OPTION3.X250

**Description**

Special dashboard panel.

Fits for	Fiat Ducato X250 Citroën Jumper / Relay Peugeot Boxer
Year	2006 - onwards
Suitable for	Left Hand Drive
Including	Screws for installation

Panel plane Option 3 DIN1

PAN.OPTION3.DIN1

**Description**

Special dashboard panel DIN1. Fits in most radio positions.

Fits for	Mercedes Sprinter WDB 906 (2006 - 2018) Renault Master ('98 - '10), ('19 - onwards) Opel/Vauxhall Movano ('98 - '10), ('19 - onwards) Nissan Interstar ('98 - '10), ('19 - onwards) Iveco (2006 - onwards)
Width	188 mm
Height	60.5 mm
Suitable for	Left and Right Hand Drive
Including	Screws for installation







Operating panel Option 1 Standard

LC.P.OP1.STA

**Description**

Complete standard operating panel option 1.

Width	160 mm
Height	65 mm
Suitable for	Left and Right Hand Drive
Including	Screws for installation

Operating panel Option 1 X244 (LHD)

LC.P.OP1.X244

**Description**

Special dashboard panel.

Fits for	Fiat Ducato X244 Citroën Jumper / Relay Peugeot Boxer
Year	2002 - 2006
Suitable for	Left Hand Drive
Including	Screws for installation

Operating panel Option 1 X244 (RHD)

LC.P.OP1.X244R

**Description**

Special dashboard panel.

Fits for	Fiat Ducato X244 Citroën Jumper / Relay Peugeot Boxer
Year	2002 - 2006
Suitable for	Right Hand Drive
Including	Screws for installation

Operating panel Option 1 X250 (LHD)

LC.P.OP1.X250

**Description**

Special dashboard panel.

Fits for	Fiat Ducato X250 Citroën Jumper / Relay Peugeot Boxer
Year	2006 - onwards
Suitable for	Left Hand Drive
Including	Screws for installation

Operating panel Option 1 X250 (RHD)

LC.P.OP1.X250R

**Description**

Special dashboard panel.

Fits for	Fiat Ducato X250 Citroën Jumper / Relay Peugeot Boxer
Year	2006 - onwards
Suitable for	Right Hand Drive
Including	Screws for installation

Operating panel Option 1 Transit '06 - '14

LC.P.OP1.FORD06

**Description**

Special dashboard panel for Ford Transit.

Fits for	Ford Transit
Year	2006 - 2014
Suitable for	Left and Right Hand Drive
Including	Screws for installation

Operating panel Option 1 Transit '14 -

LC.P.OP1.FORD14

**Description**

Special dashboard panel for Ford Transit.

Fits for	Ford Transit
Year	2014 - onwards
Suitable for	Left and Right Hand Drive
Including	Screws for installation

Operating panel Option 1 Renault Master X62

LC.P.OP1.X62

**Description**

Special dashboard panel.

Fits for	Renault Master X62 Nissan Interstar X62 Opel Movano X62
Year	2010 - 2019
Suitable for	Left and Right Hand Drive
Including	Screws for installation

Panel plane Option 1 DIN1

LC.P.OP1.DIN1

**Description**

Special dashboard panel DIN1. Fits in most radio positions.

Fits for	Mercedes Sprinter WDB 906 (2006 - 2018) Renault Master ('98 - '10), ('19 - onwards) Opel/Vauxhall Movano ('98 - '10), ('19 - onwards) Nissan Interstar ('98 - '10), ('19 - onwards) Iveco (2006 - onwards)
Width	188 mm
Height	60.5 mm
Suitable for	Left and Right Hand Drive
Including	Screws for installation



Operating panel Option 1 Iveco '14 - (LHD)

LC.P.OP1.IVE14

**Description**

Special dashboard panel for Iveco Daily.

Fits for	Iveco Daily
Year	2014 - onwards
Suitable for	Left Hand Drive
Including	Screws for installation

Operating panel Option 1 Iveco '14 - (RHD)

LC.P.OP1.IVE14R

**Description**

Special dashboard panel for Iveco Daily.

Fits for	Iveco Daily
Year	2014 - onwards
Suitable for	Right Hand Drive
Including	Screws for installation

Operating panel Option 1 Crafter / MAN TGE (LHD)

LC.P.OP1.CRA17

**Description**

Special dashboard panel for MAN TGE and Crafter.

Fits for	MAN TGE Volkswagen Crafter
Year	2017 - onwards
Suitable for	Left Hand Drive
Including	Screws for installation

Operating panel Option 1 Crafter / MAN TGE (RHD)

LC.P.OP1.CRA17R

**Description**

Special dashboard panel for MAN TGE and Crafter.

Fits for	MAN TGE Volkswagen Crafter
Year	2017 - onwards
Suitable for	Right Hand Drive
Including	Screws for installation



Operating panel Option 2 Standard

LC.P.OP2.STA

**Description**

Complete standard operating panel option 2.

Width	160 mm
Height	65 mm
Suitable for	Left and Right Hand Drive
Including	Screws for installation

Operating panel Option 2 X244 (LHD)

LC.P.OP2.X244

**Description**

Special dashboard panel.

Fits for	Fiat Ducato X244 Citroën Jumper / Relay Peugeot Boxer
Year	2002 - 2006
Suitable for	Left Hand Drive
Including	Screws for installation

Operating panel Option 2 X244 (RHD)

LC.P.OP2.X244R

**Description**

Special dashboard panel.

Fits for	Fiat Ducato X244 Citroën Jumper / Relay Peugeot Boxer
Year	2002 - 2006
Suitable for	Right Hand Drive
Including	Screws for installation

Operating panel Option 2 X250 (LHD)

LC.P.OP2.X250

**Description**

Special dashboard panel.

Fits for	Fiat Ducato X250 Citroën Jumper / Relay Peugeot Boxer
Year	2006 - onwards
Suitable for	Left Hand Drive
Including	Screws for installation

Operating panel Option 2 X250 (RHD)

LC.P.OP2.X250R

**Description**

Special dashboard panel.

Fits for	Fiat Ducato X250 Citroën Jumper / Relay Peugeot Boxer
Year	2006 - onwards
Suitable for	Right Hand Drive
Including	Screws for installation

Operating panel Option 2 Transit '06 - '14

LC.P.OP2.FORD06

**Description**

Special dashboard panel for Ford Transit.

Fits for	Ford Transit
Year	2006 - 2014
Suitable for	Left and Right Hand Drive
Including	Screws for installation

Operating panel Option 2 Transit '14 -

LC.P.OP2.FORD14

**Description**

Special operating dashboard panel for Ford Transit.

Fits for	Ford Transit
Year	2014 - onwards
Suitable for	Left and Right Hand Drive
Including	Screws for installation

Operating panel Option 2 Iveco '14 - (LHD)

LC.P.OP2.IVE14

**Description**

Special dashboard panel for Iveco Daily.

Fits for

Iveco Daily

Year

2014 - onwards

Suitable for

Left Hand Drive

Including

Screws for installation

Operating panel Option 2 Iveco '14 - (RHD)

LC.P.OP2.IVE14R

**Description**

Special dashboard panel for Iveco Daily.

Fits for

Iveco Daily

Year

2014 - onwards

Suitable for

Right Hand Drive

Including

Screws for installation

Operating panel Option 2 Crafter / MAN TGE (LHD)

LC.P.OP2.CRA17

**Description**

Special dashboard panel for MAN TGE and Crafter.

Fits for

MAN TGE
Volkswagen Crafter

Year

2017 - onwards

Suitable for

Left Hand Drive

Including

Screws for installation

Operating panel Option 2 Crafter / MAN TGE (RHD)

LC.P.OP2.CRA17R

**Description**

Special dashboard panel for MAN TGE and Crafter.

Fits for

MAN TGE
Volkswagen Crafter

Year

2017 - onwards

Suitable for

Right Hand Drive

Including

Screws for installation

Panel plane Option 2 Renault Master X62

LC.P.OP2.X62

**Description**

Special dashboard panel.

Fits for

Renault Master X62
Nissan Interstar X62
Opel Movano X62

Year

2010 - 2019

Suitable for

Left and Right Hand Drive

Including

Screws for installation

Operating panel Option 2 DIN1

LC.P.OP2.DIN1

**Description**

Special dashboard panel DIN1. Fits in most radio positions.

Fits for

Mercedes Sprinter WDB 906 (2006 - 2018)
Renault Master ('98 - '10), ('19 - onwards)
Opel/Vauxhall Movano ('98 - '10), ('19 - onwards)
Nissan Interstar ('98 - '10), ('19 - onwards)
Iveco (2006 - onwards)

Width

188 mm

Height

60.5 mm

Suitable for

Left and Right Hand Drive

Including

Screws for installation



Operating panel Option 3

LC.P.OP3

**Description**

Standard operating panel Option 3.

Width	185 mm
Height	65 mm
Suitable for	Left and Right Hand Drive
Including	Screws for installation

Operating panel Option 3 X250 (RHD)

LC.P.OP3.X250R

**Description**

Special operating dashboard panel Option 3.

Fits for	Fiat Ducato X250 Citroën Jumper / Relay Peugeot Boxer
Year	2006 - onwards
Suitable for	Right Hand Drive
Including	Screws for installation

Operating panel Option 3 X250 (LHD)

LC.P.OP3.X250

**Description**

Special dashboard panel Option 3.

Fits for	Fiat Ducato X250 Citroën Jumper / Relay Peugeot Boxer
Year	2006 - onwards
Suitable for	Left Hand Drive
Including	Screws for installation

Operating panel Option 3 DIN1

LC.P.OP3.DIN1

**Description**

Special dashboard panel DIN1. Fits in most radio positions.

Fits for	Mercedes Sprinter WDB 906 (2006 - 2018) Renault Master ('98 - '10), ('19 - onwards) Opel/Vauxhall Movano ('98 - '10), ('19 - onwards) Nissan Interstar ('98 - '10), ('19 - onwards) Iveco (2006 - onwards)
Width	188 mm
Height	60.5 mm
Suitable for	Left and Right Hand Drive
Including	Screws for installation





Option 2 Compressor with pneumatic parts

OPTION2.C5PE

**Description**

Option 2 compressor.

Including

All needed wires (2x10m)

Exclusive

All pneumatic parts
Installation material

Option 3 Compressor with pneumatic parts

OPTION3.C5PE

**Description**

Option 3 compressor.

Including

All needed wires (3x10m)

Exclusive

All pneumatic parts
Installation material

Option 2 Compressor Complete

OPTION2.C5PEC

**Description**

Option 2 compressor.

Including

All needed wires
All pneumatic parts
All installation material

Option 3 Compressor Complete

OPTION3.C5PEC

**Description**

Option 3 compressor.

Including

All needed wires
All pneumatic parts
All installation material

Assembly Pneumatic part Option 2 Comp

OP.TRK.SA.OPT.2

**Description**

Pneumatic part for Option 2.

Assembly of

T-piece
2 x Check valve
2 x Air hose connector 5 mm

Assembly Pneumatic part Option 3 Comp

OP.TRK.SA.OPT.3

**Description**

Pneumatic part for Option 3.

Assembly of

Check valve
T-piece
Air hose connector 5 mm
Pressure switch

1.21.01

**Description**

Bracket for inflate valves.

Fits for	Option valves
Position	Mostly in front of the right rear wheel. GB: left rear wheel.

SA.VENT.5MM

**Description**

Inflate / deflate valve.

Fits for	Option valves Option Mano Option 1
Including	Valve cap 5 mm air hose connector

OE.SCHAK.WIP.ZW

**Description**

Operating switch.

Fits for	Option 2
Current	25A max.

OP.VT.CP.BLM

**Description**

Push button inflate / deflate.

Fits for	Option 3
Without	Air hose connections

OP.VENT.DOP

**Description**

Cap for inflate valve.

Fits for	Option valves Option 1
----------	---------------------------

OP.VENT.BW

**Description**

Inner valve for inflate / deflate valve(s).

Fits for	Option valves Option Mano Option 1 Option 2
----------	--

OP.VT.CP.UP

**Description**

Push button deflate valve used for up.

Fits for	Option 3
Including	5 mm air hose connector

OP.VT.CP.DOWN

**Description**

Push button deflate valve used for down.

Fits for	Option 3
Including	5 mm air hose connector

OP.DIV.BLINDST

**Description**

Blind cap.

Fits for	Option 1 panel
----------	----------------

OP.MANO.DSC.10

**Description**

Pressure Gauge Dunlop Manometer 0-10 bar.

Fits for	Option Mano Option 1 Option 2 Option 3
----------	---

SA.VENT.OPTION2

**Description**

Deflate valve.

Fits for	Option 2
Including	5mm air hose connector

L.ONT.VENT.KNOP

**Description**

Deflate button.

Fits for	Option 2
----------	----------



**OPN.TRK.MF.1/8W****Description**

One way valve (check valve).
1/8 "BSP mail: 1/8" BSP
Female



Fits for	Option 2
	Option 3

OE.ZE.VZ.25A**Description**

Fuse.



Current	25A
Fits for	Option 2
	Option 3

OE.ZE.FHA.14L**Description**

Fuse holder.



Fits for	Option 2
	Option 3

OE.DS.OP3.7.5-10**Description**

Pressure switch.



Fits for	Option 3
On	7.5 bar (110 PSI)
Off	10 bar (145 PSI)
Current	20A

OE.RL.20200100M**Description**

Relay NO (Normally Open).



Fits for	Option 3
Poles	4
Current	35A
Voltage	12V

OP.DT.YE.0.5G**Description**

Air tank.



Fits for	Option 3
Volume	1.9 Liter (0.5 Gallon)
Including	5 mm air hose connectors

OPS.5X3.BLZW5**Description**

Air hose 5 mm, 5 meter Black and 5 meter Blue.

Length	Blue: 5 m Black: 5 m
Diameter	D=5 mm, d=3 mm
Position	Blue: right side Black: left side

OPS.5X3.BL10**Description**

Air hose 5 mm 10 meter Blue.

Length	10 m
Diameter	D=5 mm, d=3 mm
Colour	Blue
Position	Right side

OPN.OR.5*1/8**Description**

Fitting 5 mm air hose x 1/8" BSP.

Model	Straight
Spanner	7 mm (L) 10 mm (R)

OPN.OK.5*1/8**Description**

Elbow fitting 5 mm air hose x 1/8" BSP.

Model	Elbow
Spanner	7 mm (L) 8 mm (M)

OPS.5X3.ZW10**Description**

Air hose 5 mm 10 meter Black.

Length	10 m
Diameter	D=5 mm, d=3 mm
Colour	Black
Position	Left side

OPS.5X3.GR10**Description**

Air hose 5 mm 10 meter Green.

Length	10 m
Diameter	D=5 mm, d=3 mm
Colour	Green
Position	Compressor to air tank to panel

OPN.OV.5*5**Description**

Connector 5 mm air hose on both sides.

Model	Straight
Spanner	7 mm (L+R) 8 mm (M)

OPN.OR.5*M5**Description**

5 mm air hose x M5.

Model	Straight
Spanner	7 mm (L) 8 mm (R)

OPN.OV.5*6**Description**

Connector 5 mm air hose to 6 mm air hose.

Model	Straight
Spanner	7 mm (L) 12 mm (M) 10 mm (R)

OPN.OT.5**Description**

T-connector 5 mm air hose on all sides

Model	T
Spanner	7 mm (3x) 8 mm (M)



OPN.OR.4*1/8**Description**

Fitting 4 mm air hose x 1/8" BSP.

Model	Straight
Spanner	10 mm (L) 7 mm (R)

OPN.OK.4*1/8**Description**

Elbow fitting 1/8" BSP x 4 mm air hose.

Model	Elbow
Spanner	7 mm (R) 8 mm (M)

OPN.OV.4*5**Description**

Connector 4 mm air hose to 6 mm air hose.

Model	Straight
Spanner	7 mm (L+R) 8 mm (M)

OPN.OV.4*6**Description**

Connector 4 mm air hose to 6 mm air hose.

Model	Straight
Spanner	7 mm (L) 10 mm (R)

OPN.OV.4*4**Description**

Connector 4 mm air hose on both sides.

Model	Straight
Spanner	7 mm (L+R) 8 mm (M)

OPN.OR.4*M5**Description**

4 mm air hose x M5.

Model	Straight
Spanner	7 mm (L) 8 mm (R)

OPN.OT.4**Description**

T-connector 4 mm air hose on all sides

Model	T
Spanner	7 mm (3x) 8 mm (M)





www.dunlopsystems.nl

DSC Nederland B.V.
Het Wegdam 22
7496 CA Hengevelde
The Netherlands

T : +31 (0)547 33 30 65
F : +31 (0)547 33 30 68
E : sales@dunlopsystems.nl

